

Original Knit



Step 1
Remove Vacsoc from within corrugated tube Package. Stretch one end of the Vacsoc over top of the tube and commence to slide the entire length of Vacsoc onto the tube. Be sure to pack the Vacsoc tightly around the entire length of the tube to ensure it fits. Ensure the entire Vacsoc is on the installation tube.



Step 2
Insert wall end of vac hose through installation tube. Slide tube all the way to the handle end of the vac hose.



Step 3
Pull 2 or 3 inches of sock from tube and onto hose. Secure sock with elastic ties as close to the handle as possible.



Step 4
Slide installation tube along length of hose, allowing sock to discharge freely onto hose. Remove tube when sock has covered hose. Push any excess sock onto hose and secure with elastic ties.



Lightning Trial



CENTRAL VACUUM
FACTORY

Visit us online at:

www.CentralVacuumFactory.com