

Refilling your Desiccant Dryer Filter using the Filter Media Refill Kit for Desiccant Dryer Filter Capsules

Important Note: There are two versions of the Desiccant Dryer: One with Montmorillonite Clay Desiccant (gray granules) and One without it. **Both versions can be serviced with this Refill Package.**

Removing the Desiccants

STEP 1

Open the Desiccant Dryer
Unscrew and remove the cap. If your unit has Montmorillonite Clay (gray granules), take out the top spacer and set it aside.



STEP 2

Empty the Montmorillonite Clay (if present)
Pour the gray granules into a separate container and set aside.



STEP 3

Remove the Silica Gel Beads
Turn the dryer upside down over a container and tap it firmly until the Silica Gel Beads come out. Remove the spacer and set it aside.



STEP 4

Dispose of the Silica Gel Beads
Pour the beads into a small sealable bag and discard them according to proper disposal guidelines.



Refilling the Desiccant Dryer

STEP 1

Insert the Small Spacer
Place the smaller spacer at the bottom of the container. Make sure it's positioned as shown in the reference image (red arrow).



STEP 2

Refill with Silica Gel Beads
Using a funnel, pour new Silica Gel Beads into the container.



STEP 3

Add a Large Spacer and Pack
Place one of the large spacers on top of the beads. Use a tamping tool (or anything similar) to gently pack them down.



STEP 4

Add Montmorillonite Clay (if applicable) and fill the remaining space with the gray Montmorillonite Clay granules.



STEP 5

Finish and Seal
Place the second large spacer on top of the clay. Screw the cap back on tightly.



STEP 6

Insert Desiccant Dryer back into the Washing Machine Enhancer.

